



# Status of NATO-Standard for Nitrocellulose Testing (STANAG/AOP 4178)


Beat Vogelsanger, Michael Ramin, Marc Müller, Patrick Folly

## Contents

- Introduction
- Basis of AOP-4178 Ed. 3
- Main Changes in AOP-4178 Ed. 3
- Summary and Way Ahead

# Introduction

## Recent History of Standards for NC Testing



### Differences between STANAG/AOP-4178 and MIL-DTL-244:

STANAG/AOP-4178 is a compendium of nitrocellulose test procedures

MIL-DTL-244 is a specification for nitrocellulose that also contains test procedures (but only the ones that are needed for this specification)

# Test Methods of STANAG/AOP-4178 Ed. 3 / MIL-DTL-244C

|                                                                                                                                                                                                                                                                                                                                                                   |                                                                                                                                                                                                                                                                                                                                                                                                                                                        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Basic Characterisation</b>                                                                                                                                                                                                                                                                                                                                     | <b>Purity</b>                                                                                                                                                                                                                                                                                                                                                                                                                                          | <b>Fibre Quality</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| <ul style="list-style-type: none"> <li>▶ <u>Nitrogen Content</u> <ul style="list-style-type: none"> <li>- Ferrous Ion Titration</li> <li>- NIR Spectroscopy</li> <li>- Nitrogen Analyzer Method</li> <li>- (Devarda's Alloy Method)</li> <li>- (Schulze-Tiemann Method)</li> <li>- (Nitrometer Method)</li> <li>- (Combustion Calorimetry)</li> </ul> </li> </ul> | <ul style="list-style-type: none"> <li>▶ <u>Visual Purity Test</u></li> </ul>                                                                                                                                                                                                                                                                                                                                                                          | <ul style="list-style-type: none"> <li>▶ <u>Fineness</u></li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                 |
| <ul style="list-style-type: none"> <li>▶ <u>Ether-Alcohol Solubles</u> <ul style="list-style-type: none"> <li>- Filtration Method</li> <li>- Evaporation Method</li> </ul> </li> <li>▶ <u>Acetone Insolubles</u></li> </ul>                                                                                                                                       | <ul style="list-style-type: none"> <li>▶ <u>Ash</u></li> <li>▶ <u>Ionic Impurities</u> <ul style="list-style-type: none"> <li>- Ion Chromatography</li> <li>- Sulphate Content</li> <li>- Residual Acidity</li> <li>- Alkalinity</li> <li>- Spectroscopy / AAS/ICP</li> </ul> </li> <li>▶ <u>Oil and Grease Content</u></li> <li>▶ <u>Abel-Type Heat Tests</u> <ul style="list-style-type: none"> <li>- (76.6°C Abel Heat Test)</li> </ul> </li> </ul> | <ul style="list-style-type: none"> <li>▶ <u>Fibre Length Distribution</u></li> <li>▶ <u>(Water Retention Value)</u></li> <li>▶ <u>(Drainability)</u></li> <li>▶ <u>Fiberization Q. / Elutriation</u></li> </ul>                                                                                                                                                                                                                                                     |
| <ul style="list-style-type: none"> <li>▶ <u>132°C Stability Test</u> <ul style="list-style-type: none"> <li>- Bergmann-Junk</li> <li>- Bergmann-Junk-Siebert</li> </ul> </li> <li>▶ <u>134.5°C Heat Test (MV)</u></li> </ul>                                                                                                                                      | <ul style="list-style-type: none"> <li>▶ <u>Viscosity</u> <ul style="list-style-type: none"> <li>- Falling Ball Viscometer</li> <li>- Alternative Method</li> </ul> </li> <li>▶ <u>Mol. Mass Distribution</u></li> </ul>                                                                                                                                                                                                                               | <b>Water / Alcohol Cont.</b>                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <ul style="list-style-type: none"> <li>▶ <u>Stability</u></li> </ul>                                                                                                                                                                                                                                                                                              | <b>Polymeric Properties</b>                                                                                                                                                                                                                                                                                                                                                                                                                            | <ul style="list-style-type: none"> <li>▶ <u>Total Volatile Content</u> <ul style="list-style-type: none"> <li>- Oven Method</li> <li>- Moisture Analyzer</li> </ul> </li> <li>▶ <u>Water Content</u> <ul style="list-style-type: none"> <li>- Karl-Fischer Titration</li> <li>- Karl-Fischer Oven</li> </ul> </li> <li>▶ <u>Alcohol and/or Water</u> <ul style="list-style-type: none"> <li>- Gas Chromatography</li> <li>- NIR Spectroscopy</li> </ul> </li> </ul> |
| <b>Stability</b>                                                                                                                                                                                                                                                                                                                                                  |                                                                                                                                                                                                                                                                                                                                                                                                                                                        | <b>Others</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| <ul style="list-style-type: none"> <li>▶ <u>Ignition T / Heat of Explosion</u></li> </ul>                                                                                                                                                                                                                                                                         |                                                                                                                                                                                                                                                                                                                                                                                                                                                        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |

**Test method  
contained  
in both  
documents**


**Test method  
only in  
AOP-4178  
Ed. 3**

# Contents

- Introduction
- **Basis of AOP-4178 Ed. 3**
- Main Changes in AOP-4178 Ed. 3
- Summary and Way Ahead

# Basis of AOP-4178 Ed. 3

- **STANAG 4178 Ed. 2** (2009; ratified 2013)
  - Main basis of the revised document
  - Document fully rewritten, many parts rephrased / clarified, redundant information removed
- **MIL-DTL-244C** (2014)
  - All differences between STANAG 4178 Ed. 2 and MIL-DTL-244C eliminated
  - The 16 joint test procedures are now identical
- **International Survey / Questionnaire** (2016)
  - Survey on STANAG 4178 methods (by armasuisse)
  - 12 participating laboratories
  - Findings / conclusions included in revision
- **Workshop on NC Testing in Montreal** (2016)
  - 110 international participants
  - Findings / conclusions included in revision



# Basis of AOP-4178 Ed. 3

- **STANAG 4178 Ed. 2** (2009; ratified 2013)
  - Main basis of the revised document
  - Document fully rewritten, many parts rephrased / clarified, redundant information removed
- **MIL-DTL-244C** (2014)
  - All differences between STANAG 4178 Ed. 2 and MIL-DTL-244C eliminated
  - The 16 joint test procedures are now identical
- **International Survey / Questionnaire** (2016)
  - Survey on STANAG 4178 methods (by armasuisse)
  - 12 participating laboratories
  - Findings / conclusions included in revision
- **Workshop on NC Testing in Montreal** (2016)
  - 110 international participants
  - Findings / conclusions included in revision

METRIC  
 MIL-DTL-244C  
 w/AMENDMENT 1  
 20 May 2014  
 SUPERSEDING  
 MIL-DTL-244C  
 31 March 2014

## DETAIL SPECIFICATION

### NITROCELLULOSE

This specification is approved for use by all Departments and Agencies of the Department of Defense.

#### 1. SCOPE

1.1 Scope. This specification covers the requirements, examinations and tests for various grades, types, and classes of nitrocellulose (NC) for use in propellant and combustible case manufacturing.

1.2 Classification. Nitrocellulose is classified into the following grades, types, and classes.

| Grade      | Name                                 | Nitrogen content |
|------------|--------------------------------------|------------------|
| A Type I   | Pyrocellulose                        | 12.60 ± 0.10%    |
| A Type II  | Pyrocellulose                        | 12.60 ± 0.15%    |
| B Type I   | Guncotton                            | 13.35% minimum   |
| B Type II  | Guncotton                            | 13.20% minimum   |
| B Type III | Guncotton                            | 13.55% minimum   |
| C Type I   | Blend of pyrocellulose and guncotton | 13.15 ± 0.05%    |
| C Type II  | Blend of pyrocellulose and guncotton | 13.25 ± 0.05%    |
| D          | Pyrocellulose                        | 12.20 ± 0.10%    |
| E          | Pyrocellulose                        | 12.00 ± 0.10%    |
| F          | Pyrocellulose                        | 11.55 ± 0.25%    |

Class 1 - For combustible cartridge case (CCC) applications

Class 2 - For solvent and solventless propellant applications

Class 3 - For propellants made from lacquer applications

(Lacquer applications are propellant products that are made with completely solvated nitrocellulose from a homogenous mixture of nitrocellulose, stabilizer and solvent.)

Comments, suggestions, or questions on this document should be addressed to: Commander, U.S. Army ARDEC, ATTN: RDAR-EIQ-SE, Picatinny Arsenal, New Jersey 07806-5000, or emailed to [usarmy.picatinny.ardec.list.ardec-stdzn-branch@mail.mil](mailto:usarmy.picatinny.ardec.list.ardec-stdzn-branch@mail.mil). Since contact information can change, you may want to verify the currency of this information using ASSIST Online database at <https://assist.dla.mil>.

## Basis of AOP-4178 Ed. 3

- **STANAG 4178 Ed. 2** (2009; ratified 2013)
  - Main basis of the revised document
  - Document fully rewritten, many parts rephrased / clarified, redundant information removed
- **MIL-DTL-244C** (2014)
  - All differences between STANAG 4178 Ed. 2 and MIL-DTL-244C eliminated
  - The 16 joint test procedures are now identical
- **International Survey / Questionnaire** (2016)
  - Survey on STANAG 4178 methods (by armasuisse)
  - 12 participating laboratories
  - Findings / conclusions included in revision
- **Workshop on NC Testing in Montreal** (2016)
  - 110 international participants
  - Findings / conclusions included in revision



Even when test parameters had to be further restricted (e.g. for Nitrogen Content with FS/FAS Titration), this was done by adding a note rather than by changing the test procedure to maintain equality with MIL-DTL-244C

NOTE 7: Results of FS/FAS titration strongly depend on several experimental parameters. In particular volume and initial temperature of the sulphuric acid as well as maximum temperature during titration significantly influence the result. Main reason is that sensitivity toward these parameters is different between potassium nitrate calibration and nitrocellulose titration. Even if all parameters are kept within the range given above, not tolerable systematic deviations of obtained nitrogen content values may appear, often together with excellent precision which makes it difficult to recognize such effects. Investigations have shown that most relevant systematic effects lower the obtained nitrogen content value; e.g. due to loss of NC fibres during preparation, due to incomplete dissolution of NC in the acid, and due to loss of formed nitrogen oxides from the solution by small gas bubbles. Therefore test parameters can be optimized by targeting the maximum nitrogen content value (as the maximum value obtained is the most plausible one). Thus it was found that: (i) Adding the nitrocellulose into the dry beaker and spilling the beaker walls with sulphuric acid prevents the loss of fibres which otherwise tend to stick on acid droplets on the beaker wall above the solution. (ii) A larger amount of sulphuric acid reduces loss of formed nitrogen oxides from the solution and assists dissolving the sample; it is recommended to use 100 ml at least, better 150 ml for 300 mg of sample. (iii) Temperature of added sulphuric acid is relevant, lower temperature reduces loss of formed nitrogen oxides but slows down dissolution of sample; 5°C sulphuric acid temperature is a good compromise. (iv) Long duration of stirring ensures completeness of sample dissolution but increases loss of formed nitrogen oxides; different nitrocellulose grades might require different stirring times, typically 5 minutes to max. 30 minutes of stirring at around 5°C. (v) Maximum temperature during titration has a strong systematic influence on result due to loss of formed nitrogen oxides if temperature is too high; it is therefore strongly recommended to not exceed 25°C during entire sample dissolution and titration although both this standard and MIL-DTL-244C would allow to go up to 40°C.

## Basis of AOP-4178 Ed. 3

- **STANAG 4178 Ed. 2** (2009; ratified 2013)
  - Main basis of the revised document
  - Document fully rewritten, many parts rephrased / clarified, redundant information removed
- **MIL-DTL-244C** (2014)
  - All differences between STANAG 4178 Ed. 2 and MIL-DTL-244C eliminated
  - The 16 joint test procedures are now identical
- **International Survey / Questionnaire** (2016)
  - Survey on STANAG 4178 methods (by armasuisse)
  - 12 participating laboratories
  - Findings / conclusions included in revision
- **Workshop on NC Testing in Montreal** (2016)
  - 110 international participants
  - Findings / conclusions included in revision

### Test 2: Nitrogen Content



## Basis of AOP-4178 Ed. 3

- **STANAG 4178 Ed. 2** (2009; ratified 2013)
  - Main basis of the revised document
  - Document fully rewritten, many parts rephrased / clarified, redundant information removed
- **MIL-DTL-244C** (2014)
  - All differences between STANAG 4178 Ed. 2 and MIL-DTL-244C eliminated
  - The 16 joint test procedures are now identical
- **International Survey / Questionnaire** (2016)
  - Survey on STANAG 4178 methods (by armasuisse)
  - 12 participating laboratories
  - Findings / conclusions included in revision
- **Workshop on NC Testing in Montreal** (2016)
  - 110 international participants
  - Findings / conclusions included in revision



# Contents

- Introduction
- Basis of AOP-4178 Ed. 3
- **Main Changes in AOP-4178 Ed. 3**
- Summary and Way Ahead

# Main Changes in AOP-4178 Ed. 3 (Compared to STANAG 4178 Ed. 2)

- Procedure for **Sampling of NC** added
- Determination of **Nitrogen Content**:
  - **FAS/FS Titration**-Method improved
  - Near Infrared Spectroscopy **NIR-Method** included
  - No longer used test procedures omitted
- **65.5°C Abel Heat Test** and **Grit Test** omitted
- **Viscosity**: Alternative Viscosity Test method which is also suitable for low viscosity NC grades added
- Method for **Fibre Length Distribution** improved
- **Fiberization Quality / Agglomerates**: Wet Sieving Method replaced by Elutriation Method
- Clearly stated that some methods are only suitable for comparative testing


## 4.1.1. Sampling of Nitrocellulose

1. Nitrocellulose may be sampled at various stages of its manufacture. The samples shall be taken in their original form (e.g. as nitrocellulose slurry, as water-wet or as alcohol-wet nitrocellulose) and will require preliminary treatment before analysis can begin.
2. The sample must be representative for the respective lot to be tested. The following guidelines apply (based on MIL-DTL-244C):
  - a. **Sampling from process vessels (before pack-out)**: To ensure homogeneity of the material, the process vessel shall be stirred or vigorously agitated for an adequate time before sampling, and the slurry sample shall be obtained from the process vessel while stirring or being agitated, by a means that ensures the sample is representative of the total contents. Recommended minimum sample size for complete analysis is 500 g.
  - b. **Sampling during pack-out** (e.g. for visual purity test and for verification of total volatile, water or alcohol content, of oil and grease content, or of fiberization quality): At the container, one grab sample shall be taken from each of 10 containers or less. In case of less than 30, a minimum of 10 shall be taken beginning (first transport container) and ending (last transport container) at the third of the batch) and shall be packed. In most cases, the samples shall be packed individually. Recommended minimum sample size for complete analysis is 500 g.
  - c. **Sampling after pack-out**: The sample shall be selected for sampling from a minimum of 10 containers might be taken from a minimum of 3 containers should be taken from each lot). These samples shall be combined to form a representative sample. Recommended minimum sample size for complete analysis is 500 g.




# Main Changes in AOP-4178 Ed. 3 (Compared to STANAG 4178 Ed. 2)

- Procedure for Sampling of NC added
- Determination of Nitrogen Content:
  - **FAS/FS Titration**-Method improved
  - Near Infrared Spectroscopy **NIR-Method** included
  - No longer used test procedures omitted
- 65.5°C Abel Heat Test and Grit Test omitted
- Viscosity: Alternative Viscosity Test method which is also suitable for low viscosity NC grades added
- Method for Fibre Length Distribution improved
- Fiberization Quality / Agglomerates: Wet Sieving Method replaced by Elutriation Method
- Clearly stated that some methods are only suitable for comparative testing




**FAS/FS Titration is reference method, NIR and N-Analyzer are alternate methods; all are described in AOP-4178 Ed. 3**



**Devarda's Alloy, Schulze-Tiemann, Nitrometer and Combustion Calorimetry Methods are listed but not described in Ed. 3; they still may be used (Reference to Ed. 1 / Ed. 2)**

## Main Changes in AOP-4178 Ed. 3 (Compared to STANAG 4178 Ed. 2)

- Procedure for Sampling of NC added
- Determination of Nitrogen Content:
  - **FAS/FS Titration**-Method improved
  - Near Infrared Spectroscopy **NIR-Method** included
  - No longer used test procedures omitted
- **65.5°C Abel Heat Test** and **Grit Test** omitted
- **Viscosity**: Alternative Viscosity Test method which is also suitable for low viscosity NC grades added
- Method for **Fibre Length Distribution** improved
- **Fiberization Quality / Agglomerates**: **Wet Sieving Method** replaced by **Elutriation Method**
- Clearly stated that some methods are only suitable for comparative testing




Grit = Sand

# Main Changes in AOP-4178 Ed. 3 (Compared to STANAG 4178 Ed. 2)

- Procedure for Sampling of NC added
- Determination of Nitrogen Content:
  - **FAS/FS Titration**-Method improved
  - Near Infrared Spectroscopy **NIR-Method** included
  - No longer used test procedures omitted
- 65.5°C Abel Heat Test and Grit Test omitted
- **Viscosity**: Alternative Viscosity Test method which is also suitable for low viscosity NC grades added
- Method for Fibre Length Distribution improved
- Fiberization Quality / Agglomerates: **Wet Sieving Method** replaced by **Elutriation Method**
- Clearly stated that some methods are only suitable for comparative testing


**"MIL Viscosity" (falling sphere viscometer / 10% NC solution) remains standard viscosity method**

**Alternate viscosity method based on German TL 1376-589 (3% NC solution in acetone) allows using different viscometer types such as Hoesppler, Ubbelohde, or rotational viscometer; all viscometers give equivalent results**




# Main Changes in AOP-4178 Ed. 3 (Compared to STANAG 4178 Ed. 2)

- Procedure for Sampling of NC added
- Determination of Nitrogen Content:
  - FAS/FS Titration-Method improved
  - Near Infrared Spectroscopy **NIR-Method** included
  - No longer used test procedures omitted
- 65.5°C Abel Heat Test and Grit Test omitted
- Viscosity: Alternative Viscosity Test method which is also suitable for low viscosity NC grades added
- Method for Fibre Length Distribution improved
- Fiberization Quality / Agglomerates: Wet Sieving Method replaced by Elutriation Method
- Clearly stated that some methods are only suitable for comparative testing



Test method fully rewritten + considerably improved; automated calculation of fibre length distribution; ...



## Main Changes in AOP-4178 Ed. 3 (Compared to STANAG 4178 Ed. 2)

- Procedure for Sampling of NC added
- Determination of Nitrogen Content:
  - **FAS/FS Titration**-Method improved
  - Near Infrared Spectroscopy **NIR-Method** included
  - No longer used test procedures omitted
- 65.5°C Abel Heat Test and Grit Test omitted
- Viscosity: Alternative Viscosity Test method which is also suitable for low viscosity NC grades added
- Method for Fibre Length Distribution improved
- Fiberization Quality / Agglomerates: **Wet Sieving Method** replaced by **Elutriation Method**
- Clearly stated that some methods are only suitable for comparative testing





**Wet Sieving Method as described in Ed. 2 is not suitable for NC with low agglomerate contents and cumbersome for certain NC types**



**New Fiberization Quality Test / Elutriation Method is more robust and also applicable for NC with low agglomerate contents; on the other hand, precision is inferior for NC with extremely high agglomerate contents**

# Main Changes in AOP-4178 Ed. 3 (Compared to STANAG 4178 Ed. 2)

- Procedure for Sampling of NC added
- Determination of Nitrogen Content:
  - **FAS/FS Titration-Method** improved
  - Near Infrared Spectroscopy **NIR-Method** included
  - No longer used test procedures omitted
- 65.5°C Abel Heat Test and Grit Test omitted
- Viscosity: Alternative Viscosity Test method which is also suitable for low viscosity NC grades added
- Method for Fibre Length Distribution improved
- Fiberization Quality / Agglomerates: **Wet Sieving Method** replaced by **Elutriation Method**
- Clearly stated that some methods are only suitable for comparative testing




**Molecular Mass and Fibre Length Distribution Tests yield valuable information; their numerical results, however, strongly depend on instrument type and/or experimental conditions → only suitable for comparative testing**

# Contents

- Introduction
- Basis of AOP-4178 Ed. 3
- Main Changes in AOP-4178 Ed. 3
- **Summary and Way Ahead**

## Summary and Way Ahead

- Numerous corrections and improvements have been implemented in AOP-4178 Ed. 3
- The document is now consistent within itself and harmonised with MIL-DTL-244C
- Many persons / laboratories / agencies / institutes / companies have contributed to this revision - directly or by participating in the survey / questionnaire or NC testing workshop - this is greatly appreciated
- The final draft of AOP-4178 Ed. 3 has been submitted for NATO acceptance process



# THANK YOU FOR YOUR ATTENTION !